



# UI Bulletin #204

**Subject:** Installing Tahoe PPV/SSV Emergency Lighting and Aftermarket Equipment - Liftgate Struts Warning  
**Models Years** All Model Years  
**Affected:**  
**Models** TAHOE 9C1 PPV  
**Affected**  
**Origination** 9/25/2024  
**Date:**  
**Revision**  
**Date:** N/A

## ADVISORY:

### Condition/Concern:

Some Customers, Upfitters, or Dealers installing Tahoe Rear Strobes that need to remove the rear struts CANNOT clamp on the struts to hold open the liftgate. Use of a clamping device could damage the liftgate strut rod seals.

### Repair/Recommendation:

**WARNING:** When a liftgate hold open device is being removed or installed, provide alternate support to avoid possibility of damage to the vehicle or personal injury.

**CAUTION:** Apply pressure only at the end of the liftgate assist rod that you are removing or attaching. Do NOT apply pressure to the middle of the rod because damage or bending will result.

### NOT ACCEPTABLE EXAMPLE



### ACCEPTABLE EXAMPLE



General Motors Upfitter Integration

<http://www.gmupfitter.com>